


# HORT SCHOOL MODERNIZATION BAKERSFIELD CITY SCHOOL DISTRICT

2301 PARK DRIVE  
BAKERSFIELD, CA 93306

## DOOR DETAILS

job no.	97-276
date	JULY 8, 98
drawn by	J.L.G.
chkd by	R.T.
copyright	1998



**bfgc architects planners inc.**  
bakersfield  
5500 ring avenue, suite 450, bakersfield ca 93309-4681  
805 838-4300 fax 805 838-4311

san luis obispo  
321 broad street suite 10  
san luis obispo, california 95401  
805 547-0633

san jose  
160 west santa ana st. suite 505  
san jose, california 95131  
408 924-8941

Principal architect  
David J. Garbutt, L.A.S. C-8184  
Diane A. Goggin, L.A.S. C-8132  
James E. Sorenson, L.A.S. C-7418  
William J. Kuchel, L.A.S. C-8702  
Richard L. Webb, L.A.S. C-18078

Design & Drafting  
Diane A. Goggin, L.A.S. C-8132  
Richard L. Webb, L.A.S. C-18078

Principal contractor  
Lester & Company, L.A.S. C-9180  
George A. Sorenson, L.A.S. C-7418  
Diane A. Goggin, L.A.S. C-8132  
Richard L. Webb, L.A.S. C-18078

CONTRACTOR'S SIGNATURE  
DATE: 10/11/98  
10/11/98

1	2	3	4	5	6
3' = 1'-0"	3' = 1'-0"	3' = 1'-0"	3' = 1'-0"	1/4" = 1'-0"	3' = 1'-0"
	<p>2x STUDS @ 18" O.C. 1x4 COMMON NAILING PER BLOCK 1/4" x 3/8" BLOCKING EXTEND 1" STUD SPACE BEYOND END OF CAB. OR STUD BIR</p>	<p>8" O" MAX. CONTINUOUS BRACKING IN WALL BEHIND CABINETS. SEE OTHER DETAIL FOR ATTACHMENT TO FRAMING. #2 x 3" FLATHEAD WOOD STUDS @ 32" O.C. 1/2" x 3/8" FLATHEAD WOOD BLOCKING @ 32" O.C. 1/2" x 3/8" FLATHEAD WOOD BLOCKING @ 32" O.C.</p>	<p>4" O" MAX. WALL SUPPORTED CABINETS CONTINUOUS BRACKING IN WALL BEHIND CABINETS. SEE OTHER DETAIL FOR ATTACHMENT TO FRAMING. #2 x 3" FLATHEAD WOOD STUDS @ 32" O.C. 1/2" x 3/8" FLATHEAD WOOD BLOCKING @ 32" O.C. 1/2" x 3/8" FLATHEAD WOOD BLOCKING @ 32" O.C.</p>	<p>NOTE: SEE SHEET AS.02 FOR DOOR &amp; FRAME (FIELD VERIFY ALL DIMS). (E) WINDOWS (E) WALL H.M. FRAME TYP. A1007 A1008 A1009 A1010 A1011 A1012 S.M.</p>	<p>7 7/8" 3 7/8" 2" 2" 1/2" 1/2" TYP. (E) EXT. OVERHANG (E) 4X6 (E) WD TRIM (E) CEILING SHIM HOLLOW METAL FRAME GLAZING STOP GLASS WOOD TRIM (PAINT) HOLLOW METAL FRAME TYP. HOLLOW METAL FRAME TYP. TOOL 1/4" x 1/2" DEEP GROOVE AT ALL FRAMES SEALANT</p>
7	8	9	10	11	12
3' = 1'-0"	3' = 1'-0"	3' = 1'-0"	3' = 1'-0"	3' = 1'-0"	3' = 1'-0"
		<p>CONDITION FOR SIDE LITE OF DOOR @ GP. @ GP. BO. WALL</p> <p>FIELD VERIFY (DIMS. VARIES PER BUILDING) 5 3/4" 2" 1 3/4" 2" H.M. FRAME MATCH (E) FINISH WOOD STUDS GLAZING STOP HOLLOW METAL FRAME</p>	<p>FIELD VERIFY (DIMS. VARIES PER BUILDING) 5 3/4" 2" 1 3/4" 2" 5/8" TYP. 1/2" TYP. INTERIOR FINISH WOOD STUDS CERAMIC TILE HOLLOW METAL FRAME</p>	<p>(E) INTERIOR FINISH (E) WINDOW GLASS (E) WINDOW FRAME (E) EXTERIOR FINISH (E) WOOD HEADER (E) WINDOW GLASS HOLLOW METAL FRAME</p>	<p>CONDITION @ BUILDING "O" ONLY</p> <p>(E) EXTERIOR FINISH (E) H.M. FRAME WINDOW GLASS GLAZING STOP HOLLOW METAL FRAME H.M. FRAME DOOR TRANSOM (E) INTERIOR FINISH</p>
13	14	15	16	17	18
3' = 1'-0"	3' = 1'-0"	3' = 1'-0"	3' = 1'-0"	3' = 1'-0"	3' = 1'-0"
			<p>16   DOOR JAMB @ TOILETS 3' = 1'-0"</p>	<p>17   DOOR HEAD @ WINDOW 3' = 1'-0"</p>	<p>18   MULLION @ TRANSOM 3' = 1'-0"</p>
19	20	21	22	23	
3' = 1'-0"	3' = 1'-0"	3' = 1'-0"	3' = 1'-0"	1/4" = 1'-0"	
			<p>REFER TO DETAILS 2, 3, &amp; 4 / A1001 FOR CABINET ANCHORAGE.</p>	<p>23   RESTROOM R206 INTERIOR ELEVATIONS</p>	
25	26	26	28	28	
3' = 1'-0"	ROOM B03 INTERIOR ELEVATION	1/4" = 1'-0"	ROOM B13 INTERIOR ELEVATIONS	1/4" = 1'-0"	
	<p>EAST VINYL BASE TO REMAIN (E) CABINETS DOOR W/ SIDE LITE SEE SHEET A5.02 (E) WALL</p>		<p>REFER TO DETAILS 2, 3, &amp; 4 / A1001 FOR CABINET ANCHORAGE.</p>		